RC-50 ELECTRICAL SCHEMATIC

0200-383

WIRE DESCRIPTION

WIRE NUMBER	WIRE COLOR	DESCRIPTION
		POWER DISTRIBUTION CIRCUITS
101	RD	BAT (+)
103	YL	HOUR MTR.
104	YL	AUX. HYD. CONTROL
105	BR	KEY SWITCH
106	WH	CONSOLE/FUEL SOLENOID
108	BU	AUX. HYD. PWR.
109	OR	ALT. OUTPUT
110	GN	AUX. SW. PWR
111	YL	STARTER RLY.
112	BU	AUX. HYD. COIL #1
113	PK	AUX. HYD. MOTOR #2
120	YL	HOUR MTR. / ALT. RLY COIL
125	OR	HEATER FAN SW PWR
127	OR	AUX. HYD. CONTINUOUS SW.
128	PK	AUX. HYD. MID. LEVEL/STOCK
308	YL	MAIN PWR. RLY. COIL
309	GY	ALT. PWR. FROM DIODE
310	PU	IGN. SW. TO GLOW PLUG RLY.
321	BR	BACKUP ALARM SENDER
322	GY	HORN
521	GN	WIPER PWR
600	BR	LIGHTS
620	PK	BEACON
		CONTROL CIRCUITS
112	PU	MAIN PWR RLY OUT
117	YL	AUX. HYD. RLY. OUT #1
118	GY	AUX. HYD. RLY OUT #2
123	WH	HORN BUTTON TO HORN

WIRE NUMBER	WIRE COLOR	DESCRIPTION
		CONTROL CIRCUITS
140	BU	FROM AUX. SW
141	PK	FROM BEACON SW
143	BR	FROM FAN SW
144	GN	FROM WIPER SW
304	WH	STARTER RLY OUT
306	GN	STARTER RLY COIL TO IGN. SW
376	GN	GLOW PLUG RLY TO GLOW PLUGS
875	WH	DETENT
KS24	YL	SAFETY RLY TO SOL.
		ACCESSORY CIRCUITS
122	BU	FUEL SENDER/ALARM SENDER OUT
		LIGHTING CIRCUITS
620	WH	FLOOD LAMP FRONT
651	PK	FLOOD LAMP REAR
		MONITARY CIRCUITS
319	PK	ALT. RLY. TO AMP LIGHT
139	BU	IGN. SW TO GLOW PLUG LIGHT
		GROUND CIRCUITS
200	BK	MAIN CHASSIS
201	BK	OP. MON. RETURN
220	BK	OIL PRESS. SENDER
221	BK	COOLANT TEMP SENDER
226	BK	OIL TEMP SENDER
228	BK	FUEL LEVEL SENDER

WIRES THAT HAVE BATTERY VOLTAGE WHEN THE KEY SWITCH IS ON.

WIRES THAT HAVE BATTERY VOLTAGE WHEN THE KEY SWITCH IS ON.

STARTING CIRCUIT

GAUGE CIRCUIT

ACTION LAMP CIRCUIT

PANEL LAMP CIRCUIT

WASHER/WIPER CIRCUIT

GROUND CIRCUIT

ENGINE SHUTDOWN CONTROL CIRCUIT

OPERATOR INTERLOCK CIRCUIT

START AID CIRCUIT

DASHED LINES ARE ATTACHMENTS/OPTION

DASH/OVERHEAD CONSOLE

FUSE PANEL

BACKUP ALARM

BACKUP ALARM 0400-928

ALARM SWITCH

BACKUP ALARM SWITCH 0304-641

LEFT CONSOLE

POWER OUTLET LEFT SIDE FIREWALL

DOOR SWITCH

OPTIONAL DOOR SWITCH 0304-627

LAP BAR

LAP BAR SWITCH 0304-670

SEAT SWITCH

SEAT W/DBARTON 0304-560; SWITCH 0304-533

FUEL SENDER

FUEL SENDER 0304-536

PILOT GENERATION

SOLENOID BLOCK 0200-552

AUXILIARY SOLENOID COIL 0200-634

SAFETY SOLENOID COIL 0200-634

DA CONTROL SOLENOID COIL 0200-634

0200-200 HARNESS

HORN

FORWARD_HORN 0304-678

RIGHT CONSOLE

CONTROL HANDLE 0304-312

DETENT MAGNET 0304-516

ENGINE

INJECTION PUMP FUEL SOLENOID

ALTERNATOR

STARTER

OIL PRESS SWITCH

COOLANT TEMP SWITCH

HYD. OIL TEMP SEND 0307-679

CHASSIS GROUND INSIDE RIGHT TOWER

CHASSIS GROUND LEFT REAR SIDE OF HYDRAULIC TANK

GRND CABLE 0200-199

BATTERY 0200-160

GRND CABLE 0200-234